

# Diffraction with a Single Slit

David Cai, Congming Liao, Yian Zhang

February 14, 2020

## 1 Introduction

Single slit diffraction demonstrates the wave-particle duality of light. Depending on both the wavelength of the light and the width of the slit, interference patterns with trough.

### 1.1 Brief description

In general He-NE laser with a narrow waveband 632.8 nm is used to approximate a monochromatic source. Ideally, a prism or a spatial filter is used in order to reduce the aberration of the source. The laser beam passes through the first filter to coarsely filter the source and reshape it into a stripe. The light then passes through another filter with narrower width. The diffraction pattern can be seen the viewing screen, and direct measurements can be made with calipers. Alternatively, a photo-detector can be used by moving it transversely across the table while taking intensity measurement. Both measurement device should be installed on the right-end of the table, such that our angle argument calculated is as precise as possible.

### 1.2 Equipment

HeNe laser; calibration tool; optical breadboard Table; coarse slit on a film; a finer slit (around 100  $\mu\text{m}$ ); viewing screen; photo-detector with a coarse slit installed in front; a ruler is also required to measure the distance between the slit and the measurement device.

### 1.3 Setup

We utilize the length of the table by installing the laser on the far left-end of the table. Calibration of the laser then need to be done both vertically and then horizontally, according to laser's manual, or use the *ThorLab* alignment tool. First slit should be installed perpendicular to the light path around 10cm away from the source. The second slit should then follow closely at around 3-5cm away. Place the viewing screen on the far right end of the table such that the angle difference can be measured as precisely as possible.

## 2 Error Analysis

The uncertainties come from the width of laser beam, the width of the slit first and second, distance between the slit and the viewing screen/ detector, and the transverse displacement of the detector.

Practically, even in pure wavelength samples, we would find residual uncertainty on the wavelength by the Heisenburg's uncertainty principle  $\Delta t \cdot \Delta E \geq \frac{\hbar}{2}$ . The linewidth "full-width

at half maximum principle” can be applied in order to predict the uncertainty on the source, according to Lab Manual . We combine this into our calculation.

We estimate that the primary source of error comes from the uncertainty in the width of the slit because it is used inversely in the *arcsine* formula. Similar to the single slit experiment done with neutron, we will express our uncertainty

### 3 Data Analysis

The data we have post-experiment are the  $l$ , the distance between slit and the screen,  $d$ , the width of the slit,  $\lambda$ , the wavelength of laser, and a series of transverse displacement  $\delta d_i$ , where the peaks interference are measured. For the photo-detector, we can measure more data such that we can generate a continuous plot with peaks and troughs at various angles. The purpose of generating this plot is to compare with the amplitude plot generated by the Fresnel Integral  $I(\delta d_i)$ .

For comparisons of the result, Fresnel Diffraction and Fraunhofer Diffraction theories can be applied to compared the calculated values and measured values.

### 4 Goals

1. Verify that the wavelength  $\lambda$  is indeed 632.8 nm.
2. Verify our amplitude function  $A(\theta)$  as a function of the angle against the Fresnel Integral equation.

### References

- [1] <http://hyperphysics.phy-astr.gsu.edu/hbase/phyopt/fraunhofcon.html#c1>
- [2] <http://hyperphysics.phy-astr.gsu.edu/hbase/phyopt/fresnelcon.html>
- [3] Neutron Diffraction Paper
- [4] Manual Diffraction Manual remote experiment Project e-Xperimenteren+ J. Snellenburg, J.M.Mulder 30-01-2006
- [5] <http://www.math.ubc.ca/~cass/courses/m309-03a/m309-projects/krzak/>
- [6] Single-Slit Fresnel Diffraction Patterns: Comparison of Experimental and Theoretical Results\*<sup>t</sup> FRANKLIN S. HARRIS, JR., MICHAEL S. TAVENNER,<sup>I</sup> AND RICHARD L. MITCHELL<sup>§</sup> The Aerospace Corporation, El Segundo, California (P. O. Box 95085, Los Angeles 90045)
- [7] <http://www.sevensix.co.jp/wordpress/wp-content/uploads/2017/07/Linewidth-Application-Note-Version-1-1-October-2013.pdf>